

Battery Replacement

Always Fit a new battery when "LO BAT" is displayed



1. Completely remove the 4 screws



2. Place the tip of the screwdriver into one of the screw holes and lift up, do not lever



3. Replace the battery, the label under the old battery shows the correct way round

4. Replace the cover and 4 screws, be careful not to over tighten the screws